

Ein - Ausgang

13 12 11 10 9 8 7 6 5 4 3 2 1



14

15



16

17

18

19

20



21 22 23 24 25 26 27



41

40

39

38

37

36

35

34

42

43

44

45

46

47



31

32

33

30a

30

29

28



Ein - Ausfahrt